

Technical specifications for Lejonklou Tundra 2.5

Dimensions (WxHxD)	350x69x350 mm
Weight	4.4 kg
Mains input voltage (two versions)	90-132 or 187-264 VAC
Mains fuses (on both live and neutral)	T3.15A
Signal input impedance	10 k Ω
Signal input maximum level	1.65 VAC and 40 mVDC
Signal gain	20.8 dB (11 times)
Output impedance/Rec. load	0.05 Ω /4–16 Ω
Output power (all ratings continuous)	2*24 W into 8 Ω 20-20k Hz
RMS at less than 0.1% THD and mains voltage >103 or >207 VAC)	40 W/ch into 8 Ω at 1 kHz 70 W/ch into 4 Ω at 1 kHz
Output peak voltage	26 V
Frequency range (-3 dB)	DC to 130 kHz
Power consumption	200 W max, 30 W idling

Warning

This appliance must be earthed. Lethal voltages inside, do not open!
No user serviceable parts inside. Refer servicing to qualified personnel. To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture. Never use an appliance with a damaged power cord, as there is risk of lethal shock.

The power cord is internally colour marked as follows:

Europe/UK: Live=Brown, Neutral=Blue, Ground=Green/yellow

North America: Live=Black, Neutral=White, Ground=Green

CE Declaration of conformity:

This appliance follows the directives 73/23/EEC (LVD) and 89/336/EEC (EMC) by conforming to the following standards:

EN60065:2014 (Safety)

EN55013:2013 (Emissions)

EN55020:2007 (Immunity)



Contact information

Lejonklou HiFi AB, Skolgatan 3, 753 12 Uppsala, Sweden

Website: www.lejonklou.com, Email: info@lejonklou.com

LEJONKLOU

Tundra power amplifier

User Manual

PLEASE READ THIS MANUAL CAREFULLY!

Positioning

Position Tundra on a flat, rigid surface with plenty of space around it, so that air can circulate. The best sounding support we know is the Harmoni rack. If placing Tundra on a Harmoni shelf, make sure the four feet of Tundra are centrally positioned on the shelf. The rubber feet may appear simple in construction, but are in fact carefully chosen for optimal performance. Tighten them using your fingers only. **Never** stack units on top of each other, as the feet will leave permanent marks on the bottom unit!

Connecting (always done when switched off)

Connect your pre amplifier to the top (white) phono sockets, labelled LINE IN. As Tundra is DC-coupled, you can only use preamplifiers that have **zero** DC voltages on its output.

The input signal(s) can be daisy chained to more power amplifiers or a subwoofer by using the LINE OUT phono sockets (red). Please note that the colours white and red do **not** correspond to left and right. These connectors were chosen for best sound quality and the manufacturer refused to make them in black.

Connect your loudspeaker pair to the speaker outputs, using a cable terminated with Lejonklou 4 mm safety connectors. **Warning:** Although individual banana connectors are possible to fit, they are illegal to use in the EU for safety reasons. Use only Lejonklou 4 mm safety connectors! For optimal sound quality, we recommend **single wire** loudspeaker cable. Lejonklou offers optimal loudspeaker cables in custom lengths, using the best parts we're able to find. Please contact us if you need a pair.

When all connections have been made, you can connect the power cord and switch Tundra on. A slight "thud" in the loudspeakers is normal. Tundra will reach an optimal temperature after about 40 minutes of operation. In order to save energy, we recommend Tundra to be switched off, using the rear mains switch, when not in use for a longer period of time.

The blue lights on the front can be turned off using the switch labelled LIGHTS OFF. This switch affects the front lights **only**.

Protection – important!

Two circuits protect Tundra against internal overheating:

1: If the internal heat sink reaches 70°C, the output stage will mute, to prevent further heating. Normal operation will return once the heat sink has cooled down sufficiently.

2: If the power supplies are heated above 50°C, they will gradually derate their output in order not to become overheated.

Tundra is also protected against continuous over current.

Tundra can, however, easily be damaged by improper use:

One way is to short the speaker output terminals while the amplifier is in operation. Protecting Tundra against a sudden short circuit is not possible without loss of sound quality. Therefore such protection is intentionally omitted. In addition, no such protection circuitry is 100% effective.

Therefore: **Never** short the speaker outputs!

A second way to damage Tundra is to increase the input signal far above the maximum of 1.65 VAC. Very high input levels can result in the output stage oscillating and destroying itself.

Please note that high input levels can damage your Tundra regardless of whether loudspeakers are connected or not!

If using a Lejonklou Sagatun or similar preamp, the maximum level when listening to a digital source is **78** on the volume scale. That is where Tundra starts clipping. Do not go higher than this!

Not paying attention to the above two precautions can damage both your Tundra and the connected loudspeakers!

Lejonklou will not be held responsible for any speaker damage due to a Tundra being short circuited or driven beyond its capabilities.

We hope you will enjoy your Tundra!

If you have any questions, suggestions or encounter a problem with it, please contact your retailer or Lejonklou directly.